(Q signals continued)...

)SP	QSQ.			QSL		CON	QSD	QSB		ORZ	QRX	QRV		QRU	QRT
Will you relay to ? I will relay to	Can you communicate withdirect or by relay? I can communicate with	Did you hear me (or) onkHz? I did hear you (or) on kHz.	message or transmission)? I am acknowleging receipt.	Can you acknowledge receipt (of a	transmission? I can hear you between signals: hreak in on my transmission	Can you hear my between your signals and if so can I break in on your	Your keying is defective	Are my signals fading? Your signals are fading.	by (on kHz).	you again athours(onkHz).	When will you call me again? I will call	Are you ready? I am ready.	nothing for you.	Have you anything for me? I have	Shall I stop sending? Stop sending.

C.A.T. Deluxe Plus Morse Code Trainer User Manual

Computer Aided Technology, Inc. 4525 Production Dr Dallas, Texas 75235 ph (214) 350-0888 fax (214) 638-8887

Deluxe Morse Code Trainer

Morse Code Trainer has six different modes that can be set: Congratulation! You have just purchased a powerful tool to help you learn Morse code faster and easier. The Deluxe

programmed for different speeds and different character Mode 1 plays random codes continuously which can be

accuracy. characters. The 15 characters can be replayed to check you Mode 2 is similar to Mode 1, but pauses after every 15


every time. These QSOs are similar to General Class people. In this mode new and different QSOs are generated Mode 3 is a QSO or basically a conversation between two

numbers to be played randomly. Mode 4 allows the user to select specific characters or

the last character (this is excellent for beginners) tell the trainer when to play the next character or to repeat Mode 5 is an interactive mode which allows the users to

different words from a vocabulary list. Mode 6 is the random word group mode, which plays

Physical Layout



Specification:

Operating hours on an alkaline battery 40 hours	Power Requirements	Dimensions	Weight (without battery)
battery 40 hours	9 v battery/12v	$1 \times 2 \frac{1}{4} \times 3 \frac{3}{4}$ "	4 oz

Mode 1 Continuos Random Code

When Mode 1 is selected the trainer will play continuos random characters at a specified speed from within a specified character group. To activate Mode 1:

- 1) Power on the unit
- 2) Press **Button I** (the Select key) the number of times necessary to select the desired code speed:

15	12	70 8 8	5 4	# Times Pressed 1 2 3
27 wpm	21 wpm	15 wpm	9 wpm	Code Rate 3 wpm 5 wpm
29 wpm	23 wpm	17 wpm	11 wpm	
31 wpm	25 wpm	19 wpm	13 wpm	

Code Speed Table

- 3) After keying in the code rate, press *Button 2* (the enter key) to tell the trainer you have selected the code speed.
- 4) Press *Button I* (the Select key) once to select Mode 1 and then *Button 2* (the enter key) to tell the trainer you are finished entering the mode.
- 5) Press *Button I* the number of times need to specify the code group.

∞	7	6	5	4	ယ	2	,	# Times Pressed
Punctuation/Prosigns	0-9	R-Z	J-Q	A-I	A-Z	A-Z,0-9	All Codes	Character group

5) Press *Button 2* (the enter key) to tell the trainer you are finish programming the character group and are ready to begin code generation.

1.

Mode 2 Test for Copying Random Code

This mode is similar to Mode 1, except that it pauses every 16 characters. This pause feature allows you to check your accuracy. To activate Mode 2:

- 1) Power on the trainer.
- 2) Press Button I (the Select key) the number of times required to select the desired speed (See Word Speed Table described under Mode 1)
- 3) Press *Button 2* (the enter key) to tell DMCTP that you finish programming the code rate.
- 4) Press *Button I* twice to specify mode 2 and then *Button* 2 (the enter key).
- 5) Press Button I the number of times wanted for selecting the desired test lesson. (see character group table described under Mode 1)
- 6) Press Button 2 (the enter key) to tell the trainer you have selected the code group and are ready to begin.
- 7) The trainer will pause after playing each 15 characters in order for you to check your accuracy. Button 2, the trainer

will begin playing the a new set of 15 characters. If *Button*. *I* is pressed the trainer will repeat the last 15 characters

Mode 3 Playing Continuous New QSOs

In this mode new QSOs or conversations between two radic stations will be created every time. These QSOs are similar to the actual code exams. To activate Mode 3.

- 1) Power on the unit.
- 2) Press *Button I* (the Select key) the number of times required to select the desired speed. (See Word Speed Table described under Mode 1)
- 3) Press *Button 2* (the Enter key) to tell the trainer you have selected the word speed..
- 4) Press Button I (the Select key) three times to select Mode 3 and then press Button 2 (the Enter key). As soon as you press Button 2, the QSO will begin by playing a sequence of Vs.
- 5) After the QSO is finished, the trainer will pause to allow you to begin a new QSO by pressing *Button 2* or to repeat the same QSO by pressing *Button 1*.

The purpose of being able to repeat the same QSO is to allow you to check the accuracy of your copy.

Note: To pause the trainer, press and hold **Button 1**.

Mode 4 Selectable Random Code

This Mode will allow you to choose which characters the code trainer will randomly play. This mode is ideal for people who are weak in copying certain characters or who want to learn the characters in a specific order. To activate Mode 4:

- 1) Power on the trainer.
- 2) Press **Button 1** (the Select key) the number of times required to select the desired speed. (See Word Speed Table described under Mode 1.)
- 3) Press *Button 2* (the Enter key) to tell the trainer you have selected the word speed.
- 4) Press *Button I* (the Select key) four times to select Mode 4 and then press *Button 2* (the Enter key).
- 5) The letter A will appear on the LCD display. If Button I (the Select key) is pressed the character will be selected as on of the characters to be randomly played. If Button 2 is pressed, the character will not be selected.
- 6) After *Button I* and 2 is pressed, the letter B will appear on the LCD display. Again press *Button I* if you want to select the character and *Button 2* if you don't. The letters A

to Z and numbers 0 to 9 will sequentially appear on the LCI display allowing you to select any combination you choose.

After all the desired characters have been selected, the trainer will begin playing the selected characters randomly.

(NOTE: A MINIMUM OF THREE CHARACTERS MUS' BE SELECTED)

Mode 5 Interactive Code Training

Mode 5 is an interactive mode which allows the user to tell trainer when you are ready for the next character. This is excellent for beginners! To activate Mode 5:

- 1) Power on the trainer.
- 2) Press *Button I* (the Select key) the number of times required to select the desired speed. (See Word Speed Table described under Mode 1.)
- 3) Press Button 2 (the Enter key) to tell the trainer you have selected the word speed.
- 4) Press *Button I* (the Select key) five times to select Mode 5 and then press *Button 2* (the Enter key).
- 5) Every time you press **Button 2** a new random character will be played. To repeat the last character played, press **Button 1**.

Mode 6 Playing Random Word Groups

This mode will play groups of random words continuously. This mode is useful for preventing the user from possibly knowing what the next word might be. To activate Mode 6:

- 1) Power on the trainer.
- 2) Key in the word speed by pressing *Button I* the number of times required for the desired speed. Press *Button 2* (the enter key) after entering word speed. {see Word speed table in Mode }
- 3) Press *Button 2* (the Enter key) to tell the trainer you have selected the word speed.
- 4) Press Button I (the Select key) six times to select Mode 6 and then press Button 2 (the Enter key). At this point, the trainer will begin playing word groups.

Farnsworth Mode

To have the trainer play all characters at a fast character speed (while maintaining the selected word speed), press and hold *Button 2* down while turning on the trainer. When the trainer is set in Farnsworth mode, the cursor will take 2 seconds to appear. Once the cursor appears, you may continue to program the trainer normally, Farnsworth mode will remain in effect unit the trainer is turned off.

Code Table

\leq	Ĺ.				Ξ	47	B	(*)	D	C	\mathbf{B}	\triangleright
i I	• • •	1 • 1	1 1	•	•	i i	•	•	•	1	•	•
		× -•										

(BELOW REQUIRED FOR CODE TEST)

IMI	DN	BT	AR	AAA
quotation mark	fraction bar	pause, break	end of message	period
• • • • • • • • • • • • • • • • • • • •	•	•	• !	• ! • !

SK end of work ••	MIM comma
• • • • • • • • • • • • • • • • • • • •	i i •

Other Prosigns to Learn

AAA AF AS AL BT DN DU DU HH HH IMI IQ	period			• 1 1 • • 1 • 1 • 1	1 • • • • • • • • • •	1 • • 1 • • 1
AS AL	waitparagraph	• •		1 •	• •	•
BT	_	1 1	•		•	
DU		ı	•	•	•	1
HH	error	•	•	•	•	•
IMI	9	•	ĭ	1	•	•
IQ		•	1	1	•	1
KA	start	i.	1	•	1	
KK)	1	1	ŧ	•	1
KN	(!	t	ł	•	
KR	•		1	•	ı	•
MIM	9	1	•	•	ı	1
OS		1	1	•	•	•
SK	end of work	•	•	1	•	1
SN	understood	•	•	ı	•	

• i : : : : : : : : : : : : : : : : : :		WG
•	∽	SX

Q signals

Some examples are listed below: save time and to improve communication. Three-letter symbol beginning with Q. Used on CW to

QRA

QRG that of that of Will you tell me my exact frequency (or The name of my station is)? Your exact frequency (or

QRL Are you busy? I am busy (or I am busy

kHz.

QRM Your transmission is being interfered Is my transmission being interfered with?). Please do not interfere.

(1. nil; 2. slightly; 3. moderately; 4. severely; 5. extremely)

QRN QRM) Shall I increase power? Increase power. troubled by static___. (1-5 as under Are you troubled by static? I am

QRO QRP QRQ QRR QRR Shall I send slower?Send slower (_wpm). Shall I send faster? Send faster (_wpm). Shall I decrease power? Decrease power. am ready for automatic operation.